

Parts list of 3372

1. Nut
2. Bolt
3. Base
4. Pins
5. Holders
6. Pole
7. Funnel/Hopper (JR# 3372H)
8. Handle
9. Filter/Strainer (JR# 3372F)
10. Rod
11. Washer
12. Plunger/Press (JR# 3372P)
13. Shaft
14. Connector
15. Shaft
16. Shrapnel
17. Organizer
18. Gear
19. Socket
20. Nut
21. Connecting Rod
22. Head
23. Shrapnel
24. Pins
25. Nut
26. Pins
27. Pins

